

V Cleaning and Hygiene

After each use

- Always unplug the appliance from the mains before cleaning it.
- Do not clean the appliance when hot.
- Wait 15 minutes after use to allow the Bottle Warmer to cool down.
- Ensure that the plug does not come in contact with water.
- Wipe the inside and outside of the Bottle Warmer with a damp (not wet) cloth.

*Note: Use water of drinking quality for any described cleaning procedures
Do not clean with abrasive cleaners
Never place the Bottle Warmer directly under tap water
Never clean the Bottle Warmer in a dishwasher*

Cleaning

After a while in use limescale will build-up around the hotplate of the Bottle Warmer. This should be removed at regular intervals.

Every month (De-scale)

Version 1

- Mix **100 ml/3.3 oz** of water with citric acid* according to manufacturer's instructions and pour solution into empty Bottle Warmer.
- DO NOT place a bottle or jar into the Bottle Warmer when cleaning.
- DO NOT put lid (2) on.
- Select breastmilk, room temperature and the volume of 250 ml. After you have finished your selection, all selected icons turn on and ☺-Icon turns orange. The cleaning process has been started.
- After the cleaning process has ended, leave the solution to cool for 30 minutes before emptying the Bottle Warmer and rinsing with tap water.
- Wipe the inside and outside of the Bottle Warmer with a damp (not wet) cloth only.

Version 2

- Pour 50 ml/1.8 oz of vinegar mixed with 50 ml/1.8 oz of cold water into the Bottle Warmer.
- DO NOT place a bottle or jar into the Bottle Warmer when cleaning.
- DO NOT start the cleaning process.
- Leave liquid in the unit until limescale has dissolved.
- Empty the unit and rinse thoroughly with clear water.
- Wipe the inside and outside of the Bottle Warmer with a damp (not wet) cloth only.

**Citric acid is available from most drugstores and pharmacies*

Note: Do not use anything other than citric acid or vinegar as this may cause irreparable damage